



## LAMINATE T-MOLDING

Used to fill the gap between two floors of equal height. Most common areas are in doorways or to join two laminate floors.

**1**

Install the flooring leaving a 1-1/8" gap between the two floors for the t-molding installation.

**2**

Measure and trim to fit.

**3**

Center the track between the flooring with 1/4" spacing between the track and floor plank and screw to the subfloor using included screws.

**4**

Starting at one end, press the molding into the track inching along the length of the molding. *It will NOT snap in all at once.* You may also use a rubber mallet.